

Version

1

JESSE LUGGAGE

Custom Luggage For The World Ahead

Odyssey II Bags

For 2008 KLR650

Installation Guide



Jesse Luggage Systems

Odyssey Bags

Thank you for purchasing Jesse Luggage for your motorcycle. Our luggage, handmade in the USA, is designed for those with an interest in finding the most durable durable and functional luggage for their adventure touring. Al Jesse has been designing designing and building aluminum touring luggage since 1991. He has traveled over 40 over 40 countries on his own motorcycle and knows what it takes to make a good set of luggage. We have built in several unusual features, including hinged lids that not only hold stuff while you are unloading but also serve as additional packing space. The angles provide extra strength as well as clearance in corners and for your heels when paddling in deep sand. Powdercoating provides a durable finished look for your boxes. We hope you enjoy your luggage for years to come!

Tools Required



Parts Included

Purchase of Jesse Luggage includes mounting hardware. This hardware is shown below.

- 📁 All bolts, washers and nuts are shrink wrapped to mounting brackets. For your ease in installing the mounts, remove hardware as needed for less confusion.



- 📁 **Important:** Recommended to use **Loc-Tite® #242** (Blue-nonpermanent) on all bolts when installing mounts.

What NOT To Do!

Do **NOT** tighten any of the bolts while doing initial installation. When everything is loosely bolted together **THEN** tighten **AND** remember to use that Loc-Tite.

From here it is a good idea to review what is shown in this installation guide. Look at the images to get a feel for what you will be doing.

While following these instructions, please remember not to tighten any bolts. Hand tighten only until all mounts are installed.

Step 1. Removing stuff

Unbolt turn signals from original position and let hang from wires. Do not disconnect.

Remove front rack (8mm) allen bolt. Remove passenger pegs.

Step 2. Installing stuff



Attach Main Mount between subframe and rear passenger peg mount.



Install bolt provided into front rack mount as shown above. Insert ½" spacers between Main Mount and original turn signal mounting point. (See curved arrow above) Insert stock turn signal plate behind the spacers and install with the provided nuts & bolts.

Repeat the process on the other side.



Install Rear Support with provided 8MM allen bolts.

Tighten all bolts.

Step 3. Attach Luggage

Slide bottom Teflon on box onto lower part of Main Mount. Pivot box into position. Attach with upper Teflon disc.

Step 4. Pack and Go!